





























































Original	Replacement
 Power	 Power
 Mute	 Mute / Dimmer
 Audio / Nicam/A2	 Audio / Lang I/II
 Aspect	 Shift + Picture / Format
 P Mode	 Picture / Format
 S Mode	 Sound / Title
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 FAV	 Fav / Marker / PC
 0	 0

Original	Replacement
 Recall	 Back / Return
 Display	 Display / Media
 Freeze	 Shift + Pause / Step /
 Rec / Optional	 Shift + Rec / Rec Mode
 Rec / Optional	 Rec / Rec Mode
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 Sleep	 Sleep / Timer
 Up	 Up
 Source	 AV / Input / RDS
 Left	 Left
 Enter	 OK
 Right	 Right
 Down	 Down
 Menu	 Menu / Home





Original		Replacement		Original		Replacement	
	Exit		Exit / Cancel / Clear		S.Page / >>		>> / Preset+
	CH +		CH+ / Page+		Text		Text / Goto
	Subtitle		Subtitle / EQ		---		Guide / EPG / -/--
	Vol +		Vol+		Mouse		Smart / List
	CH -		CH- / Page-				
	Home		Shift + Menu /				
	Vol -		Vol-				
	Hold / Play/Pause		Play / Slow				
	Hold / Play/Pause		Shift + Play /				
	Hold / Play/Pause		Pause / Step / Freeze				
	Reveal / <<		<< / Tune-				
	Size / >>		Shift + >> /				
	Size / >>		>> / Tune+				
	Index / Stop		Shift + Stop /				
	Index / Stop		Stop / Hold				
	I<<		I<< / Preset-				
	S.Page / >>		Shift + >> / Preset+				

