







































































Original		Replacement		Original		Replacement	
	Power		Power		Vol+		Vol +
	Input		AV		Vol-		Vol -
	Home		Shift + Smart		CH+		Ch +
	YouTube		Smart		CH-		Ch -
	1		1		Q.View		Options
	2		2		Guide		Guide
	3		3		Menu		Menu
	4		4		Return		Back
	5		5		Exit		Exit
	6		6		3D		3D
	7		7		CH.List		List
	8		8		MTS/SAP		Dual
	9		9		CC		Subt
	0		0		Q.Menu		D. Menu
	FAV		Pre Ch		OK		Ok
	Mute		Mute		Up		Up
	Info		Info		Down		Down





Original	Replacement	Original	Replacement
 Right	 Right		
 Left	 Left		
 Sleep	 Sleep		
 S.Mode	 Shift + Dual		
 USB	 Media		
 P.Mode	 Shift + Format		
 H.Lock	 Shift + Stop		
 P.Size	 Format		
 Red	 Red		
 Play	 Play		
 Pause	 Pause		
 Green	 Green		
 <<	 <<		
 Yellow	 Yellow		
 >>	 >>		
 Blue	 Blue		
 Stop	 Stop		

