







































































Original	Replacement	Original	Replacement
	Power		Power
	Input		AV
	Sport		TV/R
	P.Mode		Format
	S.Mode		Shift + Dual
	Sleep		Sleep
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Guide		Guide
	Info		Info
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	CH.List		List
	Home		Smart
	CH+		Ch +
	CH-		Ch -
	*		Menu
	[≡]		Options
	Back		Back
	Exit		Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok



