




















































































































Original	Replacement
 Mute	 Mute / Dimmer
 Power	 Power
 More	 Display / Media
 ?	 Guide / EPG / -/--
 Sleep	 Sleep / Timer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Zoom	 Zoom / Size
 0 / AV	 0
 0 / AV	 AV / Input / RDS

Original	Replacement
 OPT	 Setup / OPT /
 SFI	 Picture / Format
 TV / Radio	 TV/Radio /
 Genre	 Smart / List
 Rec	 Rec / Rec Mode
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Red	 Red / Netflix / Search
 Up	 Up
 Blue	 Blue / Prime Video / Random
 Left	 Left
 OK	 OK
 Right	 Right
 Exit	 Exit / Cancel / Clear
 Down	 Down
 Info	 Info / Angle
 <<	 << / Tune-






























































Original	Replacement
 Mute	 Mute / Dimmer
 Power	 Power
 More	 Display / Media
 ?	 Guide / EPG / -/--
 Sleep	 Sleep / Timer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Zoom	 Zoom / Size
 0 / AV	 0
 0 / AV	 AV / Input / RDS

Original	Replacement
 OPT	 Setup / OPT /
 SFI	 Picture / Format
 TV / Radio	 TV/Radio /
 Genre	 Smart / List
 Rec	 Rec / Rec Mode
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Red	 Red / Netflix / Search
 Up	 Up
 Blue	 Blue / Prime Video / Random
 Left	 Left
 OK	 OK
 Right	 Right
 Exit	 Exit / Cancel / Clear
 Down	 Down
 Info	 Info / Angle
 <<	 << / Tune-





Original	Replacement
 Mute	 Mute / Dimmer
 Power	 Power
 More	 Display / Media
 ?	 Guide / EPG / -/--
 Sleep	 Sleep / Timer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Zoom	 Zoom / Size
 0 / AV	 0
 0 / AV	 AV / Input / RDS

Original	Replacement
 OPT	 Setup / OPT /
 SFI	 Picture / Format
 TV / Radio	 TV/Radio /
 Genre	 Smart / List
 Rec	 Rec / Rec Mode
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Red	 Red / Netflix / Search
 Up	 Up
 Blue	 Blue / Prime Video / Random
 Left	 Left
 OK	 OK
 Right	 Right
 Exit	 Exit / Cancel / Clear
 Down	 Down
 Info	 Info / Angle
 <<	 << / Tune-





Original	Replacement	Original	Replacement
	Stop		Stop / Hold
	Play / Pause		Play / Slow
	Play / Pause		Pause / Step / Freeze
	>>		>> / Tune+
	Prog -		CH- / Page-
	Prog +		CH+ / Page+
	Volume -		Vol-
	Volume +		Vol+
	TXT		Text / Goto
	Still		Shift + Pause / Step /
	Sound		Sound / Title
	PIP		D.Menu / Top
	Menu		Menu / Home
	HDMI		Shift + 0

