



Original	Replacement	Original	Replacement
Power	Power	Exit	Exit
Mute	Mute	Up/PR+	Up
1	1	Down/PR-	Down
2	2	Right	Right
3	3	Left	Left
4	4	OK/List	Ok
5	5	Vol+	Vol +
6	6	Vol-	Vol -
7	7	[+]	3D
8	8	UHF	Smart
9	9	↑	Ch +
0	0	↓	Ch -
Tv/Radio	TV/R	FAV	Pre Ch
←PR	Back	PAL/NTSC	Format
EPG	Guide	Red	Red
Menu	Menu	Green	Green
Info	Info	Yellow	Yellow





Original		Replacement		Original		Replacement	
	Blue/Sound		Blue				
	Audio		Dual				
	TXT		Text				
	[...]		Subt				
	Pause		Pause				
	Tv/AV		AV				

