







































































Original		Replacement		Original		Replacement	
	Power		Power		5		5
	Mute		Mute		6		6
	Play		Play		7		7
	[≡]		Text		8		8
	Pause/[/≡]		Pause		9		9
	Stop/[≡+]		Stop		0		0
	Rec/[≡◆]		Rec		Menu		Menu
	<</[≡0]		<<		Exit		Exit
	<</[≡]		<<		Up		Up
	>> /[≡?]		>>		Down		Down
	>> /[≡x]		>>		Right		Right
	ANT		Subt		Left		Left
	Tools		Options		OK		Ok
	1		1		Back		Back
	2		2		Home/Source		Smart
	3		3		Home/Source		AV
	4		4		Vol+		Vol +



