



|  | Original | Replacement |   | Original       | Replacement    |
|--|----------|-------------|---|----------------|----------------|
|  |          | Power       |   | Power          | Power          |
|  |          | Mute        |   | Mute           | Mute           |
|  |          | Pic Size    |   | Format         | Format         |
|  |          | Pic Mode    | + | Shift + Format | Shift + Format |
|  |          | Sleep       |   | Sleep          | Sleep          |
|  |          | Dual I-II   |   | Dual           | Dual           |
|  |          | S.Mode      | + | Shift + Dual   | Shift + Dual   |
|  |          | Still       |   | Pause          | Pause          |
|  |          | 1           |   | 1              | 1              |
|  |          | 2           |   | 2              | 2              |
|  |          | 3           |   | 3              | 3              |
|  |          | 4           |   | 4              | 4              |
|  |          | 5           |   | 5              | 5              |
|  |          | 6           |   | 6              | 6              |
|  |          | 7           |   | 7              | 7              |
|  |          | 8           |   | 8              | 8              |
|  |          | 9           |   | 9              | 9              |
|  |          | 0           |   | 0              | 0              |
|  |          | PRE-CH      |   | Pre Ch         | Pre Ch         |
|  |          | S.Swap      |   | I<<            | I<<            |
|  |          | PIP         |   | Options        | Options        |
|  |          | P.Input     |   | >>             | >>             |
|  |          | P.Position  |   | >>I            | >>I            |
|  |          | P.Size      |   | Subt           | Subt           |
|  |          | P.Swap      |   | <<             | <<             |
|  |          | TV          |   | TV/R           | TV/R           |
|  |          | PC/HDMI     |   | Media          | Media          |
|  |          | AV/Sel      |   | Smart          | Smart          |
|  |          | Source      |   | AV             | AV             |
|  |          | Menu        |   | Menu           | Menu           |
|  |          | Exit        |   | Exit           | Exit           |
|  |          | TTX/On      |   | Text           | Text           |
|  |          | Mix         | + | Shift + Text   | Shift + Text   |





| Original | Replacement   |
|----------|---------------|
|          | Up            |
|          | Ch +          |
|          | Down          |
|          | Ch -          |
|          | Right         |
|          | Vol +         |
|          | Left          |
|          | Vol -         |
|          | Ok            |
|          | Red           |
|          | Green         |
|          | Yellow        |
|          | Blue          |
|          | Shift + Smart |
|          | List          |
|          | Stop          |
|          | Back          |

| Original | Replacement |
|----------|-------------|
|          | Info        |
|          | Shift + AV  |
|          | Eject       |
|          | D. Menu     |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |

