







































































Original	Replacement	Original	Replacement
 Power	 Power	 List	 List
 Sleep	 Sleep	 Back	 Back
 Mute	 Mute	 Menu	 Menu
 Mode	 Smart	 CH +	 Ch +
 1	 1	 CH -	 Ch -
 2	 2	 Vol +	 Vol +
 3	 3	 Vol -	 Vol -
 4	 4	 Up	 Up
 5	 5	 Left	 Left
 6	 6	 OK	 Ok
 7	 7	 Right	 Right
 8	 8	 Down	 Down
 9	 9	 FAV	 Pre Ch
 0	 0	 EPG	 Guide
 Nicam/A2	 Dual	 Info	 Info
 TXT / Mix	 Text	 Exit	 Exit
 TV / Radio	 TV/R	 Red	 Red





Original		Replacement	
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Hold		Stop
	Index		Media
	Size		Eject
	Reveal		3D
	Subtitle		Subt
	Subpage		Shift + Subt
	Picture		Format
	Sound		Shift + Dual

Original		Replacement	

