







































































| Original | Replacement | Original | Replacement |
|--|---|--|---|
|  Power |  Power |  Up |  Up |
|  i |  ANGLE INFO |  RETURN |  RETURN BACK |
|  INPUT SELECT |  RDS AV INPUT |  |  Left |
|  PICTURE SIZE |  FORMAT PICTURE |  ENTER/ CH LIST |  SHIFT + OK |
|  1 |  1 |  ENTER/ CH LIST |  OK |
|  2 |  2 |  |  Right |
|  3 |  3 |  |  DIMMER MUTE |
|  4 |  4 |  |  Down |
|  5 |  5 |  |  SUBTITLE |
|  6 |  6 |  |  VOL+ |
|  7 |  7 |  |  STEP-FREEZE |
|  8 |  8 |  |  CH PAGE |
|  9 |  9 |  |  VOL- |
|  AUDIO I/II |  LANG I/II AUDIO |  |  SHIFT + RETURN BACK |
|  0 |  0 |  |  CH PAGE |
|  GUIDE EPG |  GUIDE EPG |  |  GOTO TEXT |
|  MENU |  HOME MENU |  |  SHIFT + ANGLE INFO |



