



Original	Replacement	Original	Replacement
 Power	 Power	 Left	 Left
 Mute	 Mute / Dimmer	 OK	 OK
 1	 1	 Right	 Right
 2	 2	 Down	 Down
 3	 3	 Vol +	 Vol+
 4	 4	 Info	 Info / Angle
 5	 5	 CH +	 CH+ / Page+
 6	 6	 Vol -	 Vol-
 7	 7	 Audio	 Audio / Lang I/II
 8	 8	 CH -	 CH- / Page-
 9	 9	 Red / RCL	 Red / Netflix / Search
 EPG	 Guide / EPG / -/--	 Green / Pause	 Shift + Green / APP / Repeat
 0	 0	 Green / Pause	 Green / APP / Repeat
 TV / R	 TV/Radio /	 Yellow / Sous	 Yellow / YouTube / Repeat
 Menu	 Menu / Home	 Yellow / Sous	 Shift + Yellow / YouTube / Repeat
 Sortie	 Exit / Cancel / Clear	 Blue / Text	 Shift + Blue / Prime Video / Prime
 Up	 Up	 Blue / Text	 Blue / Prime Video / Random

Original	Replacement	Original	Replacement
 Left	 Left	 Left	 Left
 OK	 OK	 OK	 OK
 Right	 Right	 Right	 Right
 Down	 Down	 Down	 Down
 Vol +	 Vol+	 Vol +	 Vol+
 Info	 Info / Angle	 Info	 Info / Angle
 CH +	 CH+ / Page+	 CH +	 CH+ / Page+
 Vol -	 Vol-	 Vol -	 Vol-
 Audio	 Audio / Lang I/II	 Audio	 Audio / Lang I/II
 CH -	 CH- / Page-	 CH -	 CH- / Page-
 Red / RCL	 Red / Netflix / Search	 Red / RCL	 Red / Netflix / Search
 Green / Pause	 Shift + Green / APP / Repeat	 Green / Pause	 Shift + Green / APP / Repeat
 Green / Pause	 Green / APP / Repeat	 Green / Pause	 Green / APP / Repeat
 Yellow / Sous	 Yellow / YouTube / Repeat	 Yellow / Sous	 Yellow / YouTube / Repeat
 Yellow / Sous	 Shift + Yellow / YouTube / Repeat	 Yellow / Sous	 Shift + Yellow / YouTube / Repeat
 Blue / Text	 Shift + Blue / Prime Video / Prime	 Blue / Text	 Shift + Blue / Prime Video / Prime
 Blue / Text	 Blue / Prime Video / Random	 Blue / Text	 Blue / Prime Video / Random





Original	Replacement	Original	Replacement
FAV	Fav / Marker / PC		
SAT	+ Shift + 0		
V.F	Setup / OPT /		
Pause	Pause / Step / Freeze		
<	+ Shift + << /		
>	+ Shift + >> /		
Rec	Rec / Rec Mode		
Play	Play / Slow		
<<	<< / Tune-		
>>	>> / Tune+		
Stop	Stop / Hold		

Original	Replacement

