










































Original	Replacement
 Power	 Power
 TV / Radio	 TV/R
 Source	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Menu	 Menu
 Guide	 Guide
 Sleep	 Sleep
 Exit	 Exit

Original	Replacement
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down
 Red / i	 Red
 Red / i	 Info
 Green / Audio	 Green
 Green / Audio	 Dual
 Yellow / Subtitle	 Yellow
 Yellow / Subtitle	 Subt
 Blue / Search	 Blue
 Blue / Search	 Shift + TV/R
 P-	 Ch -
 P+	 Ch +
 V-	 Vol -
 V+	 Vol +



