








































Original	Replacement
 Power	 Power
 Sleep	 Sleep
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 10+ / Aspect	 Shift + Guide
 Subtitle	 Subt
 Source	 AV
 -[/]- / P.STD	 Shift + Format

Original	Replacement
 -[J]- / S.STD	 Shift + Dual
 Menu	 Menu
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down
 Vol +	 Vol +
 Vol -	 Vol -
 Program +	 Ch +
 Program -	 Ch -
 Exit	 Exit
 Open / Close	 Eject
 Info	 Info
 Setup / DVD / FAV	 Options
 I/II / Audio	 Dual
 [/≡] / Text	 Text





Original		Replacement		Original		Replacement	
	Play		Play		Blue		Blue
	Pause		Pause				
	Stop		Stop				
	[≡x] / EPG		Guide				
	[≡◆] / Title / ADD		TV/R				
	Menu / SUB.		D. Menu				
	[≡+] / Goto		Format				
	[≡?] / Slow		Smart				
	[≡o] / Repeat		3D				
	[≡i] / A-B		Media				
	I<<		I<<				
	Red		Red				
	>>I		>>I				
	Green		Green				
	<<		<<				
	Yellow		Yellow				
	>>		>>				

