

























































Original	Replacement	Original	Replacement
On/Off	 Power	Menu Right	 Right
Mute	 Mute	Menu Left	 Left
Update	 Smart	OK Enter	 Ok
Reveal	 Format	Menu Off	 Exit
Txt Stop	 Stop	Back	 Back
Subt.List	 Subt	Volume+	 Vol +
Sleep Timer	 Sleep	Volume-	 Vol -
Return TV	 TV/R	Chan.Up	 Ch +
Info	 Info	Chan.Down	 Ch -
Menu video	 D. Menu	Menu audio	 Dual
Text	 Text	1	 1
Txt Expand	 Eject	2	 2
TV/AV	 AV	3	 3
Menu	 Menu	4	 4
Display	 Shift + Info	5	 5
Menu Up	 Up	6	 6
Menu Down	 Down	7	 7



Original	Replacement	Original	Replacement
8	 8	Contrast+	 Shift + Ch +
9	 9	Contrast-	 Shift + Ch -
0/10	 0	Swap	 Media
Guide -/-- 1.	 Guide	Surround	 Shift + Red
2.Fav P/C 2.	 Pre Ch	On Pip	 3D
Red	 Red	Nicam/Mono	 Shift + Green
Tone-	 I<<	Level L	 Shift + Yellow
Tone+	 >>I	Level R/Woofer	 Shift + Blue
Audio-	 <<		
Color- S.Std	 List		
Audio+	 >>		
Green	 Green		
Yellow	 Yellow		
Blue	 Blue		
On/Tim	 Shift + Subt		
Game Coo	 Shift + Eject		
Browse	 Shift + Back		

