



































































Original	Replacement	Original	Replacement
	Power		Power
	Red		Red
	Green / I-II		Green
	Green / I-II		Dual
	Yellow		Yellow
	Blue		Blue
	[i+]		Info
	[↕]		Eject
	[[]]		Pause
	[?]		Smart
	Smart Audio		Shift + Dual
	Radio		TV/R
	Smart Picture		Format
	Menu		Menu
	[≡]		Text
	Up		Up
	Left		Left
	Right		Right
	Down		Down
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	P+		Ch +
	P-		Ch -
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0



