
































































Original	Replacement	Original	Replacement
 Power	 Power	 S-Mode	 Sound / Title
 Source	 AV / Input / RDS	 Nicam / Audio	 Audio / Lang I/II
 Sleep	 Sleep / Timer	 Up	 Up
 Mute	 Mute / Dimmer	 Left	 Left
 1	 1	 Enter	 OK
 2	 2	 Right	 Right
 3	 3	 Down	 Down
 4	 4	 Red / Program	 Red / Netflix / Search
 5	 5	 Red / Program	 TV/Radio /
 6	 6	 Green / Goto	 Green / APP / Repeat
 7	 7	 Yellow / Angle	 Yellow / YouTube / Repeat
 8	 8	 Blue / USB/Card	 Blue / Prime Video / Random
 9	 9	 Subtitle	 Subtitle / EQ
 0	 0	 Info	 Info / Angle
 -/-- / +10	 Guide / EPG / -/--	 Menu / Exit	 Menu / Home
 Recall	 Back / Return	 Menu / Exit	 Exit / Cancel / Clear
 P-Mode	 Picture / Format	 + / FAV+	 Vol+

Original	Replacement	Original	Replacement
 S-Mode	 Sound / Title	 Nicam / Audio	 Audio / Lang I/II
 Up	 Up	 Left	 Left
 Enter	 OK	 Right	 Right
 Down	 Down	 Red / Program	 Red / Netflix / Search
 Red / Program	 TV/Radio /	 Green / Goto	 Green / APP / Repeat
 Yellow / Angle	 Yellow / YouTube / Repeat	 Blue / USB/Card	 Blue / Prime Video / Random
 Subtitle	 Subtitle / EQ	 Info	 Info / Angle
 Menu / Exit	 Menu / Home	 Menu / Exit	 Exit / Cancel / Clear
 Menu / Exit	 Exit / Cancel / Clear	 + / FAV+	 Vol+



