







































































Original	Replacement	Original	Replacement
 Power	 Power	 Red	 Red
 Sync Menu	 Menu	 Green	 Green
 Input	 AV	 Yellow	 Yellow
 [ ]	 Subt	 Blue	 Blue
 Audio	 Dual	 Sleep	 Sleep
 1	 1	 [i+]/[?]	 Info
 2	 2	 RETURN	 Back
 3	 3	 OPTIONS	 Options
 4	 4	 Up	 Up
 5	 5	 Down	 Down
 6	 6	 Right	 Right
 7	 7	 Left	 Left
 8	 8	 OK	 Ok
 9	 9	 HOME	 Smart
 0	 0	 Recall	 Pre Ch
 [=]	 Text	 Vol+	 Vol +
 [+]	 3D	 Vol-	 Vol -

Original	Replacement	Original	Replacement
 Red	 Red	 Green	 Green
 Yellow	 Yellow	 Blue	 Blue
 Sleep	 Sleep	 [i+]/[?]	 Info
 RETURN	 Back	 OPTIONS	 Options
 Up	 Up	 Down	 Down
 Right	 Right	 Left	 Left
 OK	 Ok	 HOME	 Smart
 Recall	 Pre Ch	 Vol+	 Vol +
 Vol+	 Vol +	 Vol-	 Vol -



