





















































Original		Replacement		Original		Replacement	
	Power		Power		I<< Skip		I<<
	1		1		Skip >>I		>>I
	2		2		<< Slow/Search		<<
	3		3		Slow/Search >>		>>
	4		4		Stop		Stop
	5		5		Pause		Pause
	6		6		Play		Play
	7		7		i/Status		Info
	8		8		X/Exit		Exit
	9		9		Option		Options
	0		0		Return		Back
	Recall/Last View		Pre Ch		Direct Navigator		List
	Radio/Tv		TV/R		Guide		Guide
	CH/Page+		Ch +		Function Menu		Menu
	CH/Page-		Ch -		Up		Up
	Internet		Smart		Down		Down
	Skype		Media		Right		Right





Original	Replacement
Left	Left
OK	Ok
Red	Red
Green	Green
Yellow	Yellow
Blue	Blue
Rec	Rec
	+
Rec Mode	Shift + Rec
Text	Text
STTL	Subt
Prog/Check	Sleep
Chapter	AV
Time Slip	Eject
Audio	Dual
Drive Select	D. Menu
	+
Del	Shift + Exit
Manual Skip -10s	Format

Original	Replacement
Manual Skip +60s	3D
	+
Power Tv	Shift + Power
	+
Av Input Tv	Shift + AV
Vol+ Tv	Vol +
Vol- Tv	Vol -
	+
CH+ Tv	Shift + Ch +
	+
CH- Tv	Shift + Ch -

