







































































Original		Replacement		Original		Replacement	
	Power		Power		Ok		Ok
	Red		Red		Menu		Menu
	Green		Green		Text		Text
	Yellow		Yellow		Stop		Stop
	Blue		Blue		1		1
	TV		TV/R		2		2
	Mute		Mute		3		3
	Smart		Smart		4		4
	Media		Media		5		5
	Up		Up		6		6
	Ch +		Ch +		7		7
	Down		Down		8		8
	Ch -		Ch -		9		9
	Left		Left		0		0
	Vol -		Vol -		Shift + Text		Shift + Text
	Right		Right		Cancel		Exit
	Vol +		Vol +		3D		3D



