







































































Original	Replacement	Original	Replacement
 Power	 Power	 Title/PopUp	 Media
 Open/Close	 Eject	 Play	 Play
 Function	 AV	 Pause/Step	 Pause
 Subtitle	 Subt	 Stop	 Stop
 Home	 Smart	 Scan >>	 >>
 Sleep	 Sleep	 << Scan	 <<
 Disc Menu	 D. Menu	 Skip >>	 >>
 Info Menu	 Info	 << Skip	 <<
 Info Menu	 Menu	 Vol+	 Vol +
 Enter	 Ok	 Vol-	 Vol -
 Up	 Up	 Mute	 Mute
 Preset+	 Ch +	 Sound Effect	 Dual
 Down	 Down	 Optical Tv Sound	 TV/R
 Preset-	 Ch -	 Speaker Level	 Options
 Right/Tuning+	 Right	 Red/RDS	 Red
 Left/Tuning-	 Left	 Green/PTY	 Green
 Back	 Back	 Yellow/PTY Search	 Yellow



