



Original	Replacement	Original	Replacement
Power	Power	0	0
Recall / [≡?]	Back	Vol+	Vol +
Mute	Mute	Vol-	Vol -
Input	AV	VIDEO+	Smart
Red	Red	A.TRK	Media
Green	Green	Sleep	Sleep
Yellow	Yellow	PR/Page+	Ch +
Blue	Blue	PR/Page-	Ch -
1	1	[≡X]	Exit
2	2	Normal	3D
3	3	[≡]	Text
4	4	Menu	Menu
5	5	Up / [ /≡]	Up
6	6	Left	Left
7	7	[≡i]	Ok
8	8	[≡i]	Info
9	9	Right	Right







Original	Replacement	Original	Replacement
 Power	 Power	 TRK+	 >>I
 Counter Reset	 Red	 TRK-	 Ch -
 Counter Stop	 Green	 TRK-	 I<<
 1	 1	 Menu	 Menu
 2	 2	 Rec/OTR	 Rec
 3	 3	 SP / LP	 Options
 4	 4	 Eject	 Eject
 5	 5	 Play	 Play
 6	 6	 REW	 <<
 7	 7	 Stop	 Stop
 8	 8	 FF	 >>
 9	 9	 Pause / Still	 Pause
 0	 0		
 Recall	 Back		
 VIDEO+	 Smart		
 A.TRK	 Media		
 TRK+	 Ch +		

