







































































Original	Replacement	Original	Replacement
 Standby - On	 Power	 Volume-	 Vol -
 Rec	 Shift + Rec	 HDD	 Red
 1	 1	 DVD	 Green
 2	 2	 TUNER	 Yellow
 3	 3	 DV	 Blue
 4	 4	 Select	 Media
 5	 5	 TV/DVD	 Smart
 6	 6	 Source	 AV
 7	 7	 DVD Rec	 Rec
 8	 8	 I<< Prev	 I<<
 9	 9	 I<< Prev	 <<
 0	 0	 >>I Next	 >>I
 Return	 Back	 >>I Next	 >>
 T/C	 Text	 Shuffle	 TV/R
 CH+	 Ch +	 Zoom	 Eject
 CH-	 Ch -	 Stop	 Stop
 Volume+	 Vol +	 Play	 Play



















	Original	Replacement		Original	Replacement
	Pause		Pause		
	Info		Info		
	Up		Up		
	Left		Left		
	OK		Ok		
	Right		Right		
	Down		Down		
	Timer		Shift + AV		
	Setup		Options		















































Original	Replacement	
On/Off		Power
Prev		Ch -
Slow Down		Shift + Left
Next		Ch +
Audio Off		Mute
Title		List
Slow Up		Shift + Right
Subt.		Subt
Auto/Track		Shift + 3D
Rep/A-B		Shift + Text
Menu		Menu
Stop		Stop
Repeat/1/All		Text
Menu Up		Up
Pause		Pause
Zoom		Eject
DVD/TV		Smart

Original	Replacement	
Menu Left		Left
OK Enter		Ok
Return		Back
Menu Right		Right
Progr.		Sleep
Display		Shift + Info
Menu Down		Down
Volume+		Vol +
Next		>>
Top Menu		D. Menu
Volume-		Vol -
1		1
Prev.		<<
2		2
Syst.Preset		Exit
3		3
4		4





Original	Replacement	Original	Replacement
5		5	
Digest	 + 	Shift + List	
6		6	
Auto Scan	 + 	Shift + Options	
Remain	 + 	Shift + Smart	
7		7	
Timer	 + 	Shift + AV	
Angle		Format	
Pbc		Yellow	
Random	 + 	Shift + TV/R	
Shuffle	 + 	Shift + D. Menu	
Key-	 + 	Shift + Down	
8		8	
9		9	
Setup		Options	
Mode	 + 	Shift + Media	
Video		AV	

Original	Replacement	Original	Replacement
Resume	 + 	Shift + Ok	
Key+	 + 	Shift + Up	
Record		Rec	
Game		Media	
R/L		Red	
Np		Green	
Audio	 + 	Shift + Dual	
Play		Play	
+10		Guide	
Karaoke/Step	 + 	Shift + Pause	
Play/Back	 + 	Shift + Play	
Echo+	 + 	Shift + Ch +	
Info		Info	
Echo-	 + 	Shift + Ch -	
Rewind		<<	
0		0	
C/CH		Pre Ch	





Original	Replacement	Original	Replacement
Search	 TV/R		
Lang	 Dual		
3D	 3D		
F.Forward	 >>		
5.1Ch	 +  Shift + 5		
2.1Ch	 +  Shift + 2		
NTSC/PAL	 +  Shift + 4		
Dimmer	 +  Shift + 0		

