



































































Original	Replacement	Original	Replacement
 Power	 Power	 Yellow	 Yellow
 Mute	 Mute	 Blue	 Blue
 1	 1	 i	 Info
 2	 2	 Text	 Text
 3	 3	 Up / P+	 Up
 4	 4	 Up / P+	 Ch +
 5	 5	 Down / P-	 Down
 6	 6	 Down / P-	 Ch -
 7	 7	 Right / Vol+	 Vol +
 8	 8	 Right / Vol+	 Right
 9	 9	 Left / Vol-	 Vol -
 0 / AV	 0	 Left / Vol-	 Left
 0 / AV	 AV	 Menu / OK	 Menu
 Red / Zoom	 Red	 Menu / OK	 Ok
 Red / Zoom	 Eject	 Stop	 Stop
 Green / Audio	 Green	 F.T/L	 Smart
Green / Audio	Dual	[?]	Media

































Original		Replacement		Original	Replacement
	[↕]	 + 	Shift + Eject		
	[⊖]		Sleep		
	>		Pre Ch		
	[X]		Exit		
	[≡i]		Format		





	Original	Replacement	Original	Replacement
	Power			
	Menu			
	OK			
	Up			
	Down			
	Right			
	Left			
	<<			
	Play			
	>>			
	Stop			
	Rec			
	↑			
	↓			





	Original	Replacement	Original	Replacement
	Power	Power		
	<<	<<		
	Play	Play		
	>>	>>		
	Rec	Rec		
	Stop	Stop		
	Up	Up		
	Down	Down		

