




































































Original	Replacement
 Standby / On	 Power
 Open/Close / Eject	 Eject
 Mute	 Mute
 Speaker	 Red
 Test	 Green
 Sound Mode	 Yellow
 Sound Mode	 Shift + Dual
 Sound Effect	 Blue
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9

Original	Replacement
 0	 0
 Angle	 Format
 Zoom / ATR.	 Shift + Eject
 Repeat / Mode	 Text
 Step	 Pause
 Prog/Trk+	 Ch +
 Prog/Trk-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 DVD	 Shift + 1
 VCR	 Shift + 2
 FM/AM	 Shift + 3
 INPUT	 AV
 INPUT	 Shift + 4
 I<< / <<	 I<<
 Stop	 Stop
 Play/Pause	 Play





Original	Replacement
 >> / >>	 >>
 Setup	 OPT Options
 Setup	 TOP MENU Menu
 Display	 DISPLAY Info
 Clear	 CLEAR Exit
 Disc Menu	 E-MANUAL D.MENU D. Menu
 Up	 Up
 Left	 Left
 Enter	 OK Ok
 Right	 Right
 Down	 Down
 Rec	 REC MODE Rec
 Return / A.Dub	 RETURN BACK Back
 Mark / Index	 FAV PRE-CH Pre Ch
 Title / Speed	 APP MEDIA Media
 Subtitle / Timer	 AD SUBT Subt
 Subtitle / Timer	 SHIFT + AV Shift + AV

Original	Replacement
 SCREEN FIT / SVHS	 HOME SMART Smart
 AUDIO	 SOUND DUAL Dual
 TV / VCR	 SEARCH TV/R TV/R
 REV	 <<< <<<
 FWD	 >>> >>>

