

















































Original	Replacement	Original	Replacement
 Power	 Power	 Up	 Up
 Source	 AV	 Left	 Left
 Rec	 Rec	 OK	 Ok
 APP	 Media	 Right	 Right
 <<	 <<	 Down	 Down
 Play / Pause	 Play	 EPG	 Guide
 Play / Pause	 Pause	 Back	 Back
 >>	 >>	 Vol+	 Vol +
 I<<	 I<<	 Vol-	 Vol -
 Stop	 Stop	 Info	 Info
 >>I	 >>I	 Mute	 Mute
 Red	 Red	 Prog+	 Ch +
 Green	 Green	 Prog-	 Ch -
 Yellow	 Yellow	 1	 1
 Blue	 Blue	 2	 2
 Menu	 Menu	 3	 3
 Exit	 Exit	 4	 4





Original	Replacement	Original	Replacement
 Power	 Power	 6	 6
 APP	 Media	 7	 7
 Menu	 Menu	 8	 8
 Exit	 Exit	 9	 9
 OK	 Ok	 0	 0
 Back	 Back	 Text	 Text
 Vol+	 Vol +		
 Vol-	 Vol -		
 Info	 Info		
 Mute	 Mute		
 Prog+	 Ch +		
 Prog-	 Ch -		
 1	 1		
 2	 2		
 3	 3		
 4	 4		
 5	 5		

