



































Original	Replacement	Original	Replacement
PWR On/Off	 Power	Menu Right	 Right
Mute	 Mute	Display	 +  Shift + Info
Epg	 +  Shift + Guide	Exit	 Exit
App	 Stop	Menu Down	 Down
Opt?	 Options	Back	 Back
Subt.List	 Subt	Volume+	 Vol +
Sleep Timer	 Sleep	CH/Page+	 Ch +
Info	 Info	Volume-	 Vol -
TV	 TV/R	Audio	 Dual
Video	 D. Menu	CH/Page-	 Ch -
Text	 Text	1. ?	 1
Zoom	 Eject	2abc	 2
TV/SAT	 AV	3def	 3
Menu	 Menu	4ghi	 4
Menu Up	 Up	5jkl	 5
Menu Left	 Left	6mno	 6
OK Enter	 Ok	7pqrm	 7



Original	Replacement	Original	Replacement
8tuv	 8	Dec/Pause	 Pause
9wxyz	 9	Lang./Rewind	 <<
Guide Pilote	 Guide	East	 >>
0/10	 0	H/V Play	 Play
FAV Pref.	 Pre Ch	LNB F.Forward	 >>
Red	 Red		
Green	 Green		
Yellow	 Yellow		
Freeze	 Media		
Blue	 Blue		
Interat	 +  Shift + D. Menu		
Dev	 3D		
	 +  Shift + Ch +		
West	 <<		
Home Cinema	 Smart		
Auth./DISEQC	 Format		
	 +  Shift + Ch -		

