

























































Original	Replacement	Original	Replacement
On/Off	 Power	OK Enter	 Ok
Mute	 Mute	Menu Right	 Right
Update	 List	Menu Off	 Exit
Reveal	 Options	Menu Down	 Down
Txt Stop	 Stop	Back	 Back
Subt.List	 Subt	Volume+	 Vol +
Sleep Timer	 Sleep	Chan.Up	 Ch +
Info	 Info	Volume-	 Vol -
Return TV	 TV/R	Menu audio	 Dual
Menu video	 D. Menu	Chan.Down	 Ch -
Text	 Text	1	 1
Txt Expand	 Eject	2	 2
TV/AV	 AV	3	 3
Menu	 Menu	4	 4
Menu Up	 Up	5	 5
Display	 Shift + Info	6	 6
Menu Left	 Left	7	 7



Original	Replacement	Original	Replacement
8	 8	Tone-	 <<
9	 9	Tone+	 >>
Guide -/-- 1.	 Guide	Color- S.Std	 +  Shift + Dual
0/10	 0	Contrast-	 +  Shift + Ch -
2.Fav P/C 2.	 Pre Ch	Nicam/Mono	 +  Shift + Green
Red	 Red	Level L	 +  Shift + Yellow
Green	 Green	Level R/Woofer	 +  Shift + Blue
Game Coo	 Play		
On/Tim	 3D		
Yellow	 Yellow		
Blue	 Blue		
Disp	 Smart		
Color+ P.Std	 Format		
Browse	 Media		
Contrast+	 +  Shift + Ch +		
Audio-	 <<		
Audio+	 >>		

