



| Original  |               | Replacement   |       | Original  |               | Replacement   |        |
|---|---------------|---|-------|---|---------------|---|--------|
|    | Power         |    | Power |    | Green / Pause |    | Green  |
|    | Mute          |    | Mute  |    | Green / Pause |    | Pause  |
|    | V+            |    | Vol + |    | Yellow / SUB  |    | Yellow |
|    | V-            |    | Vol - |    | Yellow / SUB  |    | Subt   |
|    | AV            |    | AV    |    | Blue / Text   |    | Blue   |
|    | P+            |    | Ch +  |    | Blue / Text   |    | Text   |
|    | P-            |    | Ch -  |    | FAV           |    | Pre Ch |
|    | Audio         |    | Dual  |    | TV/R          |    | TV/R   |
|    | Menu          |    | Menu  |    | EPG           |    | Guide  |
|   | Info          |   | Info  |   | 1             |   | 1      |
|  | Exit          |  | Exit  |  | 2             |  | 2      |
|  | Up / Channel+ |  | Up    |  | 3             |  | 3      |
|  | Down /        |  | Down  |  | 4             |  | 4      |
|  | Right / Vol+  |  | Right |  | 5             |  | 5      |
|  | Left / Vol-   |  | Left  |  | 6             |  | 6      |
|  | OK            |  | Ok    |  | 7             |  | 7      |
|  | Red / RCL     |  | Red   |  | 8             |  | 8      |



