










































Original	Replacement
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Tv/Radio	 TV/R
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left

Original	Replacement
 OK/List	 Ok
 Menu	 Menu
 Exit	 Exit
 Guide	 Guide
 Recall	 Back
 Green/FAV	 Green
 Red/Audio/Subtitl	 Red
 Yellow/UHF	 Yellow
 Blue/i	 Blue

