




































































Original	Replacement	Original	Replacement
 Power	 Power	 Blue	 Blue
	 Eject	 P.Mode	 Shift + Format
 1	 1	 S.Mode	 Shift + Dual
 2	 2	 Mute	 Mute
 3	 3	 TXT	 Text
 4	 4	 Aspect	 Format
 5	 5	 Audio	 Shift + 3D
 6	 6	 Display	 Info
 7	 7	 Sleep	 Sleep
 8	 8	 Up / PR +	 Up
 9	 9	 Up / PR +	 Ch +
 0	 0	 Down / PR -	 Down
 -/--	 Shift + Guide	 Down / PR -	 Ch -
 Recall	 Back	 Right / Vol +	 Right
 Red	 Red	 Right / Vol +	 Vol +
 Green	 Green	 Left / Vol -	 Left
 Yellow	 Yellow	 Left / Vol -	 Vol -





Original		Replacement		Original	Replacement
	Enter		Ok		
	Source		AV		
	Menu		Menu		
	Hold		Stop		
	Mix		Shift + Text		
	Subpage		Shift + Subt		
	Size		Shift + Eject		
	Index		3D		
	Reveal		Media		
	DTV/Radio		TV/R		
	List		List		
	EPG		Guide		
	FAV		Pre Ch		
	Page Down		I<<		
	Page Up		>>I		
	Still		Pause		
	Subtitle		Subt		

