






































Original	Replacement
 Power	 Power
 TV	 TV/R
 Source	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 List	 List
 YouTube	 Shift + Media
 Vol+	 Vol +
 Vol-	 Vol -

Original	Replacement
 Mute	 Mute
 [i]	 Info
 CH+	 Ch +
 CH-	 Ch -
 Netflix	 Media
 Home	 Smart
 *	 Menu
 Back	 Back
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Exit	 Exit
 EPG	 Guide
 Zoom	 Eject
 ≡	 Options





Original		Replacement		Original		Replacement	
	Sleep		Sleep		>>		>>
	PRE-CH		Pre Ch				
	FAV	+	Shift + Pre Ch				
	Rec		Rec				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Lang		Dual				
	Subtitle		Subt				
	Text		Text				
	I<		I<<				
	Stop		Stop				
	Play		Play				
	>I		>>I				
	<<		<<				
	Pause		Pause				

