







































































Original		Replacement		Original		Replacement	
	Power		Power		Exit / Settings		Exit
	Mute		Mute		YouTube		Media
	1		1		Vol+		Vol +
	2		2		Vol-		Vol -
	3		3		Info		Info
	4		4		EPG		Guide
	5		5		PR+		Ch +
	6		6		PR-		Ch -
	7		7		Up		Up
	8		8		Left		Left
	9		9		OK		Ok
	0		0		Right		Right
	CH List		List		Down		Down
	Return / Back		Back		Rec		Rec
	Menu		Menu		Nicam / I/II		Dual
	Source		AV		Text		Text
	Home		Smart		AD / Sub-Page		Subt





Original		Replacement		Original		Replacement	
	FAV / Size		Pre Ch				
	Quick / Hold / Freeze	 + 	Shift + Stop				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Play/Pause / Index		Play				
	Play/Pause / Index		Pause				
	<< / Reveal		<<				
	>> / Mix		>>				
	Stop / Cancel		Stop				

