






































| | Original | Replacement | | Original | Replacement |
|---|-----------|---|-------|---|-------------|
|  | Power |  | Power |  | Music |
|  | Night |  | Exit |  | Yellow |
|  | Mute |  | Mute | | |
|  | OPT 1 |  | 1 | | |
|  | AUX 2 |  | 2 | | |
|  | Bluetooth |  | Smart | | |
|  | Vol+ |  | Vol + | | |
|  | Vol- |  | Vol - | | |
|  | Voice+ |  | Up | | |
|  | Voice- |  | Down | | |
|  | Bass+ |  | Ch + | | |
|  | Bass- |  | Ch - | | |
|  | I< |  | I<< | | |
|  | Play |  | Play | | |
|  | >I |  | >>I | | |
|  | Movie |  | Red | | |
|  | Game |  | Green | | |

