































































Original		Replacement		Original		Replacement	
	Power		Power		Left		Left
	Mute		Mute		OK		Ok
	1		1		Right		Right
	2		2		Down		Down
	3		3		FAV		Pre Ch
	4		4		EPG		Guide
	5		5		V +		Vol +
	6		6		V -		Vol -
	7		7		Audio		Info
	8		8		Info		Dual
	9		9		Zoom		Eject
	0		0		CH+/Page+		Ch +
	TV/AV		AV		CH-/Page-		Ch -
	TV / R		TV/R		Red / SAT		Red
	Menu		Menu		Green / Text		Green
	Exit		Exit		Green / Text		Text
	Up		Up		Yellow / Sub		Yellow





Original	Replacement	Original	Replacement
 Yellow / Sub	 Subt		
 Red / SAT	 Smart		
 Blue / <--PR	 Blue		
 Blue / <--PR	 Back		
 Pause	 Pause		
 <I	 I<<		
 I>	 >>I		
 Rec	 Rec		
 Play	 Play		
 <<	 <<		
 >>	 >>		
 Stop	 Stop		

