
































Original	Replacement
 Power	 Power
 SD/USB- PVR	 Smart / List
 Time	 Sleep / Timer
 Mute	 Mute / Dimmer
 Vol+	 Vol+
 Source	 AV / Input / RDS
 Ch+	 CH+ / Page+
 Vol-	 Vol-
 Mode	 Picture / Format
 Ch-	 CH- / Page-
 Tv/Radio	 TV/Radio /
 Eject	 Eject / Surround
 Audio	 Audio / Lang I/II
 Play	 Play / Slow
 Pause	 Pause / Step / Freeze
 L/R	 Display / Media
 Stop	 Stop / Hold

Original	Replacement
 Subtitle / PC Auto	 Subtitle / EQ
 Menu	 Menu / Home
 Up	 Up
 Exit	 Exit / Cancel / Clear
 <<	 << / Tune-
 Left	 Left
 Ok	 OK
 Right	 Right
 Fav	 Fav / Marker / PC
 >>	 >>  / Preset+
 Down	 Down
 >>	 >> / Tune+
 Epg	 Guide / EPG / -/-
 I<<	 I<< / Preset-
 TTX/MIX	 Text / Goto
 Info/Display	 Info / Angle
 Red/Dvd Menu	 Red / Netflix / Search





Original	Replacement
 Red/Dvd Menu	 D.Menu / Top
 Green/Lang	 Green / APP / Repeat
 Green/Lang	 Shift + Audio / Lang I/II
 Yellow/Repeat	 Yellow / YouTube / Repeat
 Yellow/Repeat	 Shift + Green / APP /
 Blue/Dvd Setup	 Blue / Prime Video / Random
 Blue/Dvd Setup	 Setup / OPT /
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 -/--	 Shift + Guide / EPG / -/--

Original	Replacement
 0	 0
 Return	 Back / Return

