




































































Original	Replacement	Original	Replacement
 Power	 Power	 Pause/Step	 Pause
 Radio/Input	 TV/R	 I<< Skip	 I<<
 Open/Close	 Eject	 << Scan	 <<
 Marker	 Subt	 Scan >>	 >>
 Search	 Shift + TV/R	 Skip >>I	 >>I
 Info/Display	 Info	 Speaker Level	 Media
 Home	 Smart	 Sound Effect	 Dual
 Disc Menu	 D. Menu	 Vol +	 Vol +
 Back	 Back	 Vol -	 Vol -
 Title/Popup	 Guide	 Mute	 Mute
 Up/Presets+	 Up	 Optical	 Options
 Down/Presets-	 Down	 Red/RDS	 Red
 Right/Tuning+	 Right	 Green/PTY	 Green
 Left/Tuning-	 Left	 Yellow/PTY Search	 Yellow
 Enter	 Ok	 Blue/Mono Stereo	 Blue
 Stop	 Stop	 1	 1
 Play	 Play	 2	 2





Original	Replacement
DEF 3	3
GHI 4	4
JKL 5	5
MNO 6	6
PQRS 7	7
TUV 8	8
WXYZ 9	9
0	0
CLEAR	EXIT
REPEAT	TEXT
SLEEP	SLEEP
REC	REC MODE
*	ECO 3D
*	TIMER AV
POWER	SHIFT + [Power] Shift + Power
AV/INPUT	SHIFT + [TIMER AV] Shift + AV
PR/CH	+ CH Ch +

Original	Replacement
PR/CH v	CH - Ch -
+ VOL	SHIFT + + VOL Shift + Vol +
VOL -	SHIFT + VOL - Shift + Vol -
MUTE	SHIFT + MUTE Shift + Mute

