


































































































| Original | Replacement | Original | Replacement |
|--|---|---|---|
|  Power |  Power |  SA-CD/CD |  Media |
|  Open/Close |  Eject |  Shuffle |  Yellow |
|  1 |  1 |  A-B |  Shift + Play |
|  2 |  2 |  Audio |  Dual |
|  3 |  3 |  Subtitle |  Subt |
|  4 |  4 |  Angle |  Red |
|  5 |  5 |  Picture Navi |  3D |
|  6 |  6 |  Time/Text |  Text |
|  7 |  7 |  Repeat |  Shift + Text |
|  8 |  8 |  Sur |  Options |
|  9 |  9 |  Picture Mode |  Format |
|  0 |  0 |  Search Mode |  TV/R |
|  Clear |  Exit |  Replay |  Shift + I<< |
|  Enter |  Pre Ch |  I<< |  I<< |
|  TV/DVD / Input |  AV |  >>I |  >>I |
|  Aspect |  Shift + Format |  < [<<] |  Ch - |
|  SA-CD |  Smart |  [>>] > |  Ch + |

































Multi/2CH



| Original | Replacement | Original | Replacement |
|--|---|----------|-------------|
|  << Scan/<I |  << | | |
|  Scan >>/Slow |  >> | | |
|  Play |  Play | | |
|  Pause |  Pause | | |
|  Stop |  Stop | | |
|  Up |  Up | | |
|  Left |  Left | | |
|  Enter |  Ok | | |
|  Right |  Right | | |
|  Down |  Down | | |
|  Display |  Info | | |
|  Menu |  Menu | | |
|  Top Menu |  D. Menu | | |
|  Return |  Back | | |
| | | | |
| | | | |
| | | | |





| | Original | Replacement | Original | Replacement |
|---|----------|---|----------|-------------|
|  | Power |  | | |
|  | 1 |  | | |
|  | 2 |  | | |
|  | 3 |  | | |
|  | 4 |  | | |
|  | 5 |  | | |
|  | 6 |  | | |
|  | 7 |  | | |
|  | 8 |  | | |
|  | 9 |  | | |
|  | 0 |  | | |
|  | Enter |  | | |
|  | TV/DVD |  | | |
|  | Vol+ |  | | |
|  | Vol- |  | | |
| | | | | |
| | | | | |

