












































































Original	Replacement
 Power	 Power
 Eject	 Eject / Surround
 Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 OSD / Info	 Display / Media
 OSD / Info	 Info / Angle
 4	 4
 5	 5
 6	 6
 V-Mode	 Picture / Format
 7	 7
 8	 8
 9	 9
 P/N / Fav	 Fav / Marker / PC
 0	 0

Original	Replacement
 10+	 Shift + Guide / EPG / -/-
 Goto	 Shift + Text /
 Setup	 Setup / OPT /
 Angle	 Shift + Info / Angle
 Text / Title	 Sound / Title
 Text / Title	 Text / Goto
 Subtitle	 Subtitle / EQ
 Menu	 Menu / Home
 Up	 Up
 Left	 Left
 Enter	 OK
 Right	 Right
 Down	 Down
 PBC / EPG	 Guide / EPG / -/-
 Source	 AV / Input / RDS
 Exit	 Exit / Cancel / Clear
 <<	 << / Tune-





Original		Replacement	
	Play / Pause		Play / Slow
	Play / Pause		Pause / Step / Freeze
	I<<		I<< / Preset-
	>>		>> / Tune+
	Stop		Stop / Hold
	>>I		>>I / Preset+
	Red / Prog		TV/Radio /
	Red / Prog		Red / Netflix / Search
	Green / Step		Green / APP / Repeat
	Green / Step		Shift + Pause / Step /
	Yellow / Repeat		Yellow / YouTube / Repeat
	Yellow / Repeat		Shift + Green / APP /
	Blue / A-B		Blue / Prime Video / Random
	Blue / A-B		Shift + Yellow / YouTube /
	Zoom		Zoom / Size
	Slow		Shift + Play /
	Vocal		D.Menu / Top

Original		Replacement	
	Audio		Audio / Lang I/II
	CH-		CH- / Page-
	CH+		CH+ / Page+
	Vol-		Vol-
	Vol+		Vol+

