







































































Original	Replacement	Original	Replacement
 Power	 Power	 Slow	 AV
 Mute	 Mute	 Menu	 Menu
 1	 1	 EPG	 Guide
 2	 2	 Exit	 Exit
 3	 3	 Zoom	 Smart
 4	 4	 Navi	 Media
 5	 5	 Play	 Play
 6	 6	 Pause	 Pause
 7	 7	 <<	 <<
 8	 8	 >>	 >>
 9	 9	 Rec	 Rec
 0	 0	 Stop	 Stop
 Info	 Info	 UP	 Up
 ADV	 Pre Ch	 Down	 Down
 Page+	 >>	 Right	 Right
 Page-	 <<	 Left	 Left
 Audio	 Dual	 OK	 Ok





Original	Replacement	Original	Replacement
CH+	Ch +		
CH-	Ch -		
Vol+	Vol +		
Vol-	Vol -		
TV/Radio	TV/R		
Teletext	Text		
Subtitle	Subt		
Return	Back		
Red	Red		
Green	Green		
Yellow	Yellow		
Blue	Blue		

