































































































































Original	Replacement	Original	Replacement
	Power		Power
	Audio		Dual
	[+]		Format
	Digital		Media
	Analog		Smart
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	[≡]		Text
	Recall		Pre Ch
	Mute		Mute
	Vol+		Vol +
	Vol-		Vol -
	[i+]		Info
	Menu/Home		Menu
	Return/Exit		Exit
	Return/Exit		Back
	CH+		Ch +
	CH-		Ch -
	Tools/Options		Options
	[:≡]		Guide





Original	Replacement	Original	Replacement
	Power		Power
	Menu		Menu
	Top Menu		D. Menu
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Clear		Exit
	Enter		Pre Ch
	F1		Smart
	F2		Media
	[: =]		Guide
	Display		Info
	Tools/Options		Options
	Return/Exit		Back
	Menu/Home		TV/R
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Mute		Mute
	Vol+		Vol +
	Vol-		Vol -
	I<<		I<<
	>>I		>>I
	Play		Play
	Pause		Pause









































































Original	Replacement	Original	Replacement
	Stop		Stop
	<<		<<
	>>		>>
	↑		Ch -
	→		Ch +















Original		Replacement		Original		Replacement	
	Power		Power		Clear		Exit
	Menu		Menu		Display		Info
	Top Menu		D. Menu		Tools/Options		Options
	F1		Smart		Mute		Mute
	F2		Media		Vol+		Vol +
	[:=]		Guide		Vol-		Vol -
	1		1		Return/Exit		Back
	2		2		Menu/Home		TV/R
	3		3		Up		Up
	4		4		Down		Down
	5		5		Right		Right
	6		6		Left		Left
	7		7		OK		Ok
	8		8		Play		Play
	9		9		Pause		Pause
	0		0		Stop		Stop
	Enter		Pre Ch		>>		>>









































































	Original	Replacement	Original	Replacement
	<<	 <<		
	>>	 >>		
	<<	 <<		
	↑	 Ch -		
	↓	 CH +		





Original		Replacement		Original		Replacement	
	Power		Power		Display		Info
	Source		AV		Mute		Mute
	1		1		Vol+		Vol +
	2		2		Vol-		Vol -
	3		3		Menu/Home		Media
	4		4		Return/Exit		Back
	5		5		Up		Up
	6		6		OK		Ok
	7		7		Down		Down
	8		8		Right		Right
	9		9		Left		Left
	0		0		Play		Play
	Clear		Exit		Stop		Stop
	Enter		Pre Ch		Pause		Pause
	Theatre		Smart		>>/Tuning+		>>
	Sound Field		Dual		<</Tuning-		<<
	AMP Menu		Menu		>>I/Preset+		>>I





Original	Replacement	Original	Replacement
I<</Preset-	I<<		
→	Ch +		
←	Ch -		
DMPort	Options		
Video	Shift + 1		
BD	Shift + 3		
DVD	Shift + 4		
SAT	Shift + 5		
TV	Shift + 6		
Tuner/Band	Shift + 8		

Original	Replacement

