


































Original	Replacement
 Power	 Power
 Source	 AV
 P.Mode	 Format
 S.Mode	 Shift + Dual
 Home	 Smart
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Q.View	 Options
 Sleep	 Sleep

Original	Replacement
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 I/II/Audio	 Dual
 P+	 Ch +
 P-	 Ch -
 Subtitle	 Subt
 3D World	 3D
 Info	 Info
 FAV	 Pre Ch
 Screen	 Media
 CH List	 List
 Menu	 Menu
 Guide	 Guide
 Back	 Back
 Exit	 Exit
 Up	 Up





Original	Replacement	Original	Replacement
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			

