






































Original	Replacement
 Power	 Power
 Mute	 Mute
 TV / AV	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Recall	 Back
 SAT	 Smart
 Menu	 Menu
 EPG	 Guide








Original	Replacement
 Info	 Info
 Exit	 Exit
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down
 Vol+	 Vol +
 Vol-	 Vol -
 Page+	 Ch +
 Page-	 Ch -
 Red / Audio	 Red
 Red / Audio	 Dual
 Green / 	 Green
 Yellow / Text	 Yellow
 Yellow / Text	 Text
 Blue / Find	 Blue









Original	Replacement	Original	Replacement
Power		Power	
Mute		Mute	
Recall		Back	
EPG		Guide	
Info		Info	
1		1	
2		2	
3		3	
4		4	
5		5	
6		6	
7		7	
8		8	
9		9	
0		0	
Menu		Menu	
Exit		Exit	

Original	Replacement	Original	Replacement
Up		Up	
Left		Left	
OK		Ok	
Right		Right	
Down		Down	
PAL / NTSC		Format	
FAV		Pre Ch	
TV / Radio		TV/R	
SAT		Smart	
TV / AV		AV	
Play / Pause		Play	
Play / Pause		Pause	
Zoom		Eject	
Red / Audio		Red	
Red / Audio		Dual	
Green / Position		Green	
Yellow / Text		Yellow	



