



































































































Original	Replacement
 Power	 Power
 Input	 AV
 Tv/Radio	 TV/R
 Sync Menu	 Menu
 Digital/Analog	 Format
 Exit	 Exit
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 [i+]/[?]	 Info

Original	Replacement
 [=]	 Text
 Google Play	 Shift + Smart
 Netflix	 Media
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 TV	 3D
 Guide	 Guide
 Action Menu	 D. Menu
 Discover	 Options
 Back	 Back
 Home	 Smart
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left





Original		Replacement		Original		Replacement	
	OK		Ok		Help		Eject
	Vol+		Vol +		[...]		Subt
	Vol-		Vol -				
	Mute		Mute				
	Prog+		Ch +				
	Recall		Pre Ch				
	Prog-		Ch -				
	Audio		Dual				
	<<		<<				
	Play		Play				
	>>		>>				
	I<<		I<<				
	Pause		Pause				
	>>I		>>I				
	Rec		Rec				
	Stop		Stop				
	Title List		List				

