







































































Original		Replacement		Original		Replacement	
	Power		Power		Setup		Options
	Open/Close		Eject		<< FR/SR		<<
	1		1		>> FF/SF		>>
	2		2		Up		Up
	3		3		Down		Down
	4		4		Right		Right
	5		5		Left		Left
	6		6		Sel		Ok
	7		7		I<<		I<<
	8		8		Display		Info
	9		9		>>I		>>I
	0		0		Title		List
	Clear		Exit		Menu		Menu
	PBC		Guide		Marker		TV/R
	Stop/Return		Stop		Angle		Red
	Play/Pause		Play		Subtitle		Subt
	>I</Step		Pause		Audio		Dual





Original	Replacement
Zoom	+ Shift + Eject
3D Sound	3D
Repeat	Text
Program	Sleep
Shuffle	Media
Digest	Yellow
A-B	+ Shift + Play
Vol+	Vol +
Vol-	Vol -

Original	Replacement

