







































































Original	Replacement
 Power	 Power
 Power Tv	 Shift + Power
 Vol+ Tv	 Vol+
 CH+ TV	 Shift + CH+ /
 AV Input Tv	 AV / Input / RDS
 Vol- Tv	 Vol-
 CH- Tv	 Shift + CH- /
 1	 1
 2	 2
 3	 3
 Rec	 Rec / Rec Mode
 4	 4
 5	 5
 6	 6
 CH+	 CH+ / Page+
 7	 7
 8	 8

Original	Replacement
 9	 9
 CH-	 CH- / Page-
 Last View	 Shift + Back / Return
 0	 0
 Drive Select	 Display / Media
 Prog/Check	 Menu / Home
 -10s	 Fav / Marker / PC
 +60s	 Shift + Guide / EPG / -/-
 Internet	 Smart / List
 Netflix	 Shift + Red / Netflix /
 <<	 << / Tune-
 Play	 Play / Slow
 >>	 >> / Tune+
 I<<	 I<< / Preset-
 Pause	 Pause / Step / Freeze
 >>I	 >>I / Preset+
 Stop	 Stop / Hold





Original		Replacement	
	i/Status		Info / Angle
	Guide		Guide / EPG / -/--
	Exit		Exit / Cancel / Clear
	Video Menu		Shift + 4
	Up		Up
	Function Menu		D.Menu / Top
	Left		Left
	OK		OK
	Right		Right
	Option		Setup / OPT /
	Down		Down
	Return		Back / Return
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	Audio		Audio / Lang I/II

Original		Replacement	
	Delete		Shift + Exit / Cancel / Clear
	Text		Text / Goto
	STTL		Subtitle / EQ

