




























































Original		Replacement		Original		Replacement	
	Power		Power		[Z]		Format
	Open/Close		Eject		Camera		3D
	[]X		Smart		(Z))		Dual
	EQ		Media		Time		AV
	Mute		Mute		Prog		Sleep
	→[]←		Subt		Setup/Mem		Options
	1		1		Title		List
	2		2		Menu/PBC		Menu
	3		3		Return/Exit		Back
	4		4		Up		Up
	5		5		Down		Down
	6		6		Right/FAV+		Right
	7		7		Left/FAV-		Left
	8		8		Enter		Ok
	9		9		Function		Pre Ch
	0		0		Tv/Radio		TV/R
	+10		Guide		DVD		D. Menu





Original		Replacement		Original	Replacement
	Stop		Stop		
	Play/Pause		Play		
	Slow		Pause		
	Info		Info		
	<</Tuning-		<<		
	>>/Tuning+		>>		
	I<</Channel-		I<<		
	>>I/Channel+		>>I		
	Teletext		Text		
	EPG		Shift + Guide		
	Vol+		Vol +		
	Vol-		Vol -		
	Red/Repeat		Red		
	Green/A-B		Green		
	Yellow/Zoom		Yellow		
	Blue/Clear		Blue		

