





















































Original	Replacement
 Power	 Power
 Fn	 Media
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Fav	 Pre Ch
 0	 0
 SAT	 3D
 Page Up	 >>
 Page Down	 <<

Original	Replacement
 Menu	 Menu
 Exit	 Exit
 Up	 Up
 Left	 Left
 Ok / List	 Ok
 Right	 Right
 Vol+	 Vol +
 Down	 Down
 Ch+	 Ch +
 Vol-	 Vol -
 Ch-	 Ch -
 Info	 Info
 Tv/Radio	 TV/R
 Pause	 Pause
 EPG	 Guide
 Av/Tv	 AV
 Uhf	 Smart



