



Original	Replacement
	Power
	Subtitle / EQ
	Audio / Lang I/II
	Eject / Surround
	Vol+
	Smart / List
	CH+ / Page+
	Vol-
	Mute / Dimmer
	CH- / Page-
	Sleep / Timer
	Green / APP / Repeat
	Up
	Menu / Home
	Info / Angle
	<< / Tune-
	I<< / Preset-

Original	Replacement
	Left
	Stop / Hold
	OK
	>> / Tune+
	>>I / Preset+
	Right
	TV/Radio /
	Play / Slow
	Pause / Step / Freeze
	Down
	Rec / Rec Mode
	D.Menu / Top
	Shift + Sleep / Timer
	Display / Media
	Setup / OPT /
	1
	2



