





Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute / Dimmer
	V+		Vol+
	V-		Vol-
	Menu		Menu / Home
	AV		AV / Input / RDS
	Audio		Audio / Lang I/II
	Info		Info / Angle
	P+		CH+ / Page+
	P-		CH- / Page-
	Exit		Exit / Cancel / Clear
	Channel Up		Up
	Channel Down		Down
	Right/Vol+		Right
	Left/Vol-		Left
	OK		OK
	Red/RCL		Red / Netflix / Search
	Green/Pause		Green / APP / Repeat
	Yellow/Sub		Yellow / YouTube / Repeat
	Blue/text		Blue / Prime Video / Random
	List		Smart / List
	Tv/R		TV/Radio /
	EPG		Guide / EPG / -/--
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	SAT		Shift + 0





Original	Replacement	Original	Replacement
	Zoom		Zoom / Size

