




































































Original	Replacement
	
Power	Power
	
Source	AV / Input / RDS
	
[=]	Text / Goto
	
I-II	Audio / Lang I/II
	
[...]	Subtitle / EQ
	
Red	Red / Netflix / Search
	
Green	Green / APP / Repeat
	
Yellow	Yellow / YouTube / Repeat
	
Blue	Blue / Prime Video / Random
	
Menu	Menu / Home
	
EPG	Guide / EPG / -/--
	
Up	Up
	
<<	<< / Tune-
	
Play	Play / Slow
	
Pause	Pause / Step / Freeze
	
>>	>> / Tune+
	
Down	Down

Original	Replacement
	
Option	Shift + Setup / OPT / Tools
	
[i+]	Info / Angle
	
Vol+	Vol+
	
Stop	Stop / Hold
	
Page+	CH+ / Page+
	
Vol-	Vol-
	
Mute	Mute / Dimmer
	
Page-	CH- / Page-
	
1	1
	
2	2
	
3	3
	
FAV	Fav / Marker / PC
	
4	4
	
5	5
	
6	6
	
J/Slideshow	TV/Radio /
	
7	7





Original		Replacement	
	8		8
	9		9
	Rotate		Display / Media
	Setup		Setup / OPT /
	0		0
	[<>]		Picture / Format
	Zoom		Zoom / Size

Original		Replacement	

