


























































Original	Replacement	Original	Replacement
 Power	 Power	 Right	 Right
 Guide	 Guide / EPG / -/--	 Left	 Left
 Input Tv	 TV/Radio /	 OK	 OK
 Input AV	 AV / Input / RDS	 Red	 Red / Netflix / Search
 Menu	 Menu / Home	 Green	 Green / APP / Repeat
 Text	 Text / Goto	 Yellow	 Yellow / YouTube / Repeat
 STTL/AD	 Subtitle / EQ	 Blue	 Blue / Prime Video / Random
 Aspect	 Picture / Format	 Vol+	 Vol+
 Info	 Info / Angle	 Vol-	 Vol-
 Exit	 Exit / Cancel / Clear	 Mute	 Mute / Dimmer
 Netflix	 Shift + Red / Netflix /	 CH+	 CH+ / Page+
 Home	 Shift + Menu /	 CH-	 CH- / Page-
 APPS	 Shift + Green / APP /	 1	 1
 Option	 Setup / OPT /	 2	 2
 Return	 Back / Return	 3	 3
 Up	 Up	 4	 4
 Down	 Down	 5	 5

Original	Replacement	Original	Replacement
 Right	 Right	 Left	 Left
 Left	 Left	 OK	 OK
 OK	 OK	 Red	 Red / Netflix / Search
 Red	 Red / Netflix / Search	 Green	 Green / APP / Repeat
 Green	 Green / APP / Repeat	 Yellow	 Yellow / YouTube / Repeat
 Yellow	 Yellow / YouTube / Repeat	 Blue	 Blue / Prime Video / Random
 Blue	 Blue / Prime Video / Random	 Vol+	 Vol+
 Vol+	 Vol+	 Vol-	 Vol-
 Vol-	 Vol-	 Mute	 Mute / Dimmer
 Mute	 Mute / Dimmer	 CH+	 CH+ / Page+
 CH+	 CH+ / Page+	 CH-	 CH- / Page-
 CH-	 CH- / Page-	 1	 1
 1	 1	 2	 2
 2	 2	 3	 3
 3	 3	 4	 4
 4	 4	 5	 5



